

MEMTECH

AT2515 2.5" Bulldog

2.5" IDE Solid State Flash Drive

User Guide

80-03-00036

Revision 1.1

April 2006

**Memtech SSD Corporation
2107 N. First Street, Suite 415**

San Jose, CA 95131

(408) 452-1277

(800) 445-5511

www.memtech.com



Table of Contents

1. HIGHLIGHTS	3
2. INTRODUCTION	3
3. INSTALLATION	4
3.1 PROCEDURE	4
3.2 JUMPERS	6
3.3 IDE INTERFACE	8
4. OPERATION	10
4.1 ECC	10
4.2 WEAR OUT	10
4.3 POWER	11
5. MAINTENANCE	12
6. SPECIFICATIONS	13
6.1 INTERFACE	13
6.2 PERFORMANCE*	13
6.3 ENVIRONMENTAL	13
6.4 POWER REQUIREMENTS	13
6.5 MECHANICAL	13
7. APPENDIX	14
7.1 CONTACT INFORMATION	14
7.2 ATA SPECIFICATION INFORMATION	14
7.3 LIMITED LIFETIME WARRANTY	14



1. HIGHLIGHTS

- 128Mbyte to 8 Gbytes uncompressed capacity
- Full -40°C to +85°C operating temperature range
- 5 volt, low power operation
- Completely solid state - no moving parts and no batteries
- Extremely Rugged - 1000G operating shock, 15G operating vibration
- Low profile 2.5" drive form factor only 9mm tall
- Standard a 44-pin, 2mm IDE interface
- Transfers with PIO Mode 4 and DMA Mode 2 support
- 72-bit Reed-Solomon ECC for exceptional data reliability
- Power hold-up circuit
- 0.3 millisecond access time
- 6 Mbytes/second sustained Read throughput
- 6 Mbytes/second sustained Write throughput
- Pending CE and CSA Safety Compliance

2. INTRODUCTION

The AT2515 is the low cost member of the Bulldog family of drives available today. With a capacity of 8 Gbytes in a standard 2.5" drive form factor, it delivers exceptional value for its features. It is completely solid state, with no moving parts. This accounts for the unit's exceptional ruggedness and wide operating temperature range.

The AT2515 employs sector erasable NAND EEPROMs (Flash) to deliver up to 8 Gbytes of uncompressed, non-volatile solid state storage in an extremely small, rugged form factor. Sustained host data throughput is 6 Mbytes per seconds for reads and 6 Mbytes/second for writes. The drive supports up to PIO Mode-4 and DMA Mode-2 IDE bus access. It is 100% IDE compatible and requires no special drivers to operate. It is essentially a drop in replacement for standard rotating media.

The IDE interface is implemented using an application specific IDE Flash controller with an integrated 72-bit Reed-Solomon error detection and on-the-fly correction mechanism that enhance data reliability. The ECC circuitry, in conjunction with the controller's remapping algorithms, makes for a virtually bulletproof medium for data retention.

The drive is available in a number of standard capacities ranging from 128 Mbytes to 8 Gbytes. Please contact the factory with your capacity requirements. Disk compression utilities may be used to effectively double the usable capacity of the drive.

Each drive is fully tested under environmental and voltage extremes, to guarantee data integrity in even the harshest conditions.



3. INSTALLATION

3.1 PROCEDURE

3.1.1 ESD PRECAUTIONS

Static electricity kills... electronics! Before handling the AT2515, please observe the following precautions to avoid ESD damage to the unit:

- Keep the drive in its shielded bag until ready to install.
- Ground yourself by touching a grounded chassis frame of the computer, or use a grounded wrist strap before and during the installation process.
- Do not touch the exposed drive electronics or connectors. Always handle the drive by the edges or mounting rails.

3.1.2 CONFIGURATION

Configure the drive using the jumper diagrams given in Section 3.2. The drive is shipped configured for a single drive system or as the master in a two-drive system. Change the configuration as required. Never attempt to change the jumpers while the drive is plugged in or power is applied.

3.1.3 CONNECTOR

The drive may be interfaced directly to a standard 2.5" 2mm IDE socket connector or a standard 2mm, 44-pin IDE ribbon cable. A separate power cable is not required since the 2mm socket or ribbon cable connector supplies both signals and power. See drawing below for pin 1 location. Care should be taken when installing the AT2515 into the system, as misalignment can permanently damage the drive interface connector or electronics.




Figure 1 - Drive Connector



3.1.4 MOUNTING

The AT2515 may be mounted in any orientation. A total of eight bottom and eight side mounting holes are available for installation. The mounting holes require M3 screws with a maximum depth of 5 mm.

The diagram given below is valid for all capacities of the AT2515 drive. The outline dimensions are 2.75" (69.85 mm) wide, 3.94" (100.2mm) long, and 0.315" (8.00mm) tall. Please refer to the following drawing for dimensions and mounting hole locations




Figure 2 - Mechanical Dimensions

3.1.5 COMPUTER SETUP

To be recognized by the computer, the drive translation information must typically be entered into the System Setup or CMOS Setup utility. For non-PC compatible computers, this may not apply. The AT2515 supports automatic detection and configuration if offered by the BIOS. If the drive configuration must be manually entered, select drive type USER and use the table below to determine proper setup parameters. Automatic CHS translation and LBA mode is supported. Note that a MB is equal to 1024*1024 bytes.



Drive Type	Physical Capacity	Cylinders	Heads	Sectors	Available Capacity
AT2515-128	128 MB	977	8	32	122 MB
AT2515-256	256 MB	980	16	32	245 MB
AT2515-384	384 MB	745	16	63	366 MB
AT2515-512	512 MB	993	16	63	489 MB
AT2515-768	768 MB	1489	16	63	732 MB
AT2515-1024	1024MB	1986	16	63	977 MB
AT2515-2048	2048MB	3969	16	63	1953 MB
AT2515-3072	3072MB	5953	16	63	2930 MB
AT2515-4096	4096MB	7937	16	63	3906.5 MB
AT2515-6144	6144MB	11628	16	63	5723.2 MB
AT2515-8192	8192MB	15504	16	63	7630.9 MB

3.1.6 PARTITION

The drive must be partitioned using the system's FDISK utility. For operating systems other than DOS, please refer to your OS operating guides. Note that changing the partition information will erase all data currently on the drive. Refer to your OS manual for information regarding partitioning a hard disk.

3.1.7 FORMAT

The AT2515 is low-level formatted at the factory, which establishes the 512-byte sector size. A high-level format is required after the partition has been established on the drive. Refer to your OS manual for information regarding hard disk drive format procedures.

3.2 JUMPERS

The following diagram illustrates the location of the drive configuration jumpers on the AT2515. The jumpers control the drive selection - master, slave or cable select. The jumper required is a 2-pin vertical header on 2mm centers.





Figure 3 - Configuration Jumpers

3.2.1 MASTER/SLAVE




Master/Slave Jumper

The master/slave jumper allows the drive to be configured as either master or slave.

Installing the jumper allows the drive to be configured as a slave. With the jumper off, the drive is configured as a master.

3.2.2 CABLE SELECT




Cable Select Jumper



The Cable Select jumper allows the drive to be configured as a master or slave through the IDE cable. A maximum of two drives may only be connected to one standard IDE cable. Connecting the drive to the end of the cable configures the drive to be a master (DOS drive C:) and connecting the drive to the middle connector of the cable configures the drive for a slave (DOS drive D:).

With the Cable Select jumper off, the drive to uses the master/slave jumper for drive configuration.

3.2.3 FACTORY DEFAULT



Factory Default – Master

The factory default configuration is as the master drive with no jumpers installed.

3.3 IDE INTERFACE

The AT2515 uses a 44-pin 2mm connector mounted on the PCB to create both a power and signal connection to the host. Maximum cable length is 18 inches. Recommended cable length is 12 inches or less, especially if advanced PIO transfer modes are used.

3.3.1 IDE CONNECTOR ADAPTER

An adapter or interposer for converting the 2mm IDE connector to a standard 40-pin 0.100" IDE connector is available from the factory. Order part number 153264-002. The adapter converts the drive 44-pin 2mm connector to a standard 40-pin 0.100" connector. Power arrives via a 4-pin Amp power header (EI series) identical to the connector used to supply power to 3.5-inch floppy drives. To convert the 4-pin Amp power connector to a standard 4-pin AT power connector, an ATA power cable adapter, part number 153273-002, is included.




Figure 4 - IDE Adapter Board

3.3.2 IDE CONNECTOR PINOUT




Figure 5 - IDE Connector



The following table depicts the 44-pin, 2mm-signal cable interface pinout.

PIN	SIGNAL	PIN	SIGNAL
1	RESET-	2	GND
3	DATA7	4	DATA8
5	DATA6	6	DATA9
7	DATA5	8	DATA10
9	DATA4	10	DATA11
11	DATA3	12	DATA12
13	DATA2	14	DATA13
15	DATA1	16	DATA14
17	DATA0	18	DATA15
19	GND	20	KEY (NO PIN)
21	DMARQ	22	GND
23	IOW-	24	GND
25	IOR-	26	GND
27	IOCHRDY	28	CSEL
29	DMACK-	30	GND
31	IRQ	32	IOCS16-
33	ADDR1	34	PDIAG-
35	ADDR0	36	ADDR2
37	CS0-	38	CS1-
39	DASP-	40	GND
41	+5VOLTS	42	+5VOLTS
43	GND	44	RESERVED

4. OPERATION

4.1 ECC

The IDE controller utilizes a 72-bit Reed-Solomon Error Detection Code (EDC) and Error Correction Code (ECC), which provides the following error immunity for each 512-byte block of data:

1. Corrects up to three random 12-bit symbol errors.
2. Corrects single bursts up to 25 bits.

4.2 WEAR OUT

The time to failure can be logically calculated in hours using the following formula.

$$\text{Wear Out} = \frac{\# \text{ Flash Chips} * \# \text{ Blocks} * \text{Re-programming Cycles} * \text{Area Rate}}{\text{Average Block Programming Rate per hour (Block = 16Kbyte)}}$$

Note: The program area is the area that is not changed once it has been programmed. The remainder of the drive is thus considered "Reprogrammable". In the case where 64 Kbytes (128 sectors) are written every minute into an area occupying 30% of a 512 MB disk (1 Gbit x 4 chips), the MTBF is calculated as shown below:



$$\begin{aligned}\text{Wear Out} &= (4 \times 8192 \times 100,000 \times 0.3) / [(64/16) \times 60] \\ &= 4.1 \text{ million hours (465 years)}\end{aligned}$$

4.3 POWER

4.3.1 POWER DOWN

The AT2515 is shipped with Memtech's proprietary Kicker™ hold-up circuit. The Kicker™ provides enough residual power for the drive to complete a write sequence, thus avoiding data corruption.


Still, it is recommended that power not be removed from any mass storage device while a write sequence is in progress. This is especially true when disk-caching programs are being used. Though the Kicker™ protects against data corruption and media errors, it cannot prevent OS or file errors from occurring. These types of errors arise when the OS breaks a large transfer into many smaller ones, and only part of the transfer arrives from the host.

4.3.2 POWER SUPPLY

The AT2515 voltage requirement is specified at +5 volts, +/- 5%. Operation outside of these limits is not guaranteed. Note that the drive will "operate" below this voltage, but reliability issues such as uncorrectable errors or invalid data reads may occur. An on board voltage monitor will inhibit writes when the on-board supply voltage falls below 3 volts, thus preserving data integrity on the drive.

4.3.3 POWER ROUTING

Bad power can lead to bad data. To avoid "glitches" or noise on the Vcc and ground lines, power in the system should be routed so that all peripherals are sourced from the power supply in a star configuration, as opposed to routing a single continuous supply line to each device in the system. Routing power in the star configuration, as is done on most desktop PCs, will minimize the effect on one device's current draw on another device. This is key to maintaining data integrity on the AT2515. See diagrams below.





5. MAINTENANCE

No maintenance is required during the normal use of this drive.

If data is to be archived for long periods of time (> 10 years), it is recommended that the data on the drive be refreshed every 5 to 10 years. The manufacturer of the NAND E²PROM devices will only guarantee data integrity for a period of 10 years. Programs such as Norton Speedisk[®], which reallocates all sectors on the drive, or Microsoft[®] Scandisk, which writes and reads every sector on the disk during its surface test, achieve this end very well.



6. SPECIFICATIONS

6.1 INTERFACE

IDE Compatibility	X3T10 2008D, Rev. 7b
IDE Drive Number	Drive 0 or 1
Physical Capacity	128 Mbytes to 8 Gbytes
Physical Sector Size	512 bytes

6.2 PERFORMANCE*

Average Access	0.3 ms
Track/Track Access	0.3 ms
Sequential Read	6 Mbytes/sec sustained
Sequential Write	6 Mbytes/sec sustained
Random Read	6 Mbytes/sec sustained
Random Write	6 Mbytes/sec sustained

6.3 ENVIRONMENTAL

Commercial Temperature Range	
Operating	0° to 70° C
Storage	-55° C to 125° C
Extended Temperature Range	
Operating	-20° C to 75° C
Storage	-55° C to 125° C
Industrial Temperature Range	
Operating	-40° to 85° C
Storage	-55° to 125° C
Shock - operating	1500G, 0.5mS, Operating
Vibration - operating	15G Random
Airflow	None required
Humidity	5% to 95% NC

6.4 POWER REQUIREMENTS

Voltage	5V +/- 5%
Current	AT2515-1024
Idle	1.5 mA
Read	35 mA
Write	45 mA

6.5 MECHANICAL

Length	3.94 inches (102.00 mm)
Width	2.75 inches (69.85 mm)
Height	.35 inches (9.00 mm)
Cable Interface	44-pin, 2mm centers
Max. Cable Length	18 inches (457 mm)
Rec. Cable Length	12 inches (305 mm)
Weight	(2048 Mbytes) 2.9 oz (208 g)



7. APPENDIX

7.1 CONTACT INFORMATION

For Technical Support or Warranty Repair information, please contact Memtech at:

Memtech SSD Corporation
2107 N. First Street, Suite 415
San Jose, CA 95131
phone: (408) 452-1277 or (800) 445-5511
fax: (408) 452-7936

7.2 ATA SPECIFICATION INFORMATION

Information regarding the ATA-3 specification may be obtained from the following locations:

AT-Attachment Document Distribution
Global Engineering
15 Inverness Way East
Englewood, Co. 80112-5704
Phone: (303) 792-2181 or (800) 854-7179
Fax: (303) 792-2192

ATA Anonymous FTP Site
<http://fission.dt.wdc.com>
ATA3 directory is: "/pub/standards/ata/ata-3"

7.3 LIMITED LIFETIME WARRANTY

Memtech warrants your AT2515 against defects in material and workmanship for the life of the drive. The warranty is void in the case of misuse, accident, alteration, improper installation, misapplication or the result of unauthorized service or repair.

The implied warranties of merchantability and fitness for a particular purpose, and all other warranties, expressed or implied, except as set forth in this warranty, shall not apply to the products delivered.

In no event shall Memtech be liable for any lost profits, lost savings or other incidental or consequential damages arising out of the use of, or inability to use, this product.

BEFORE RETURNING PRODUCT, A RETURN MATERIAL AUTHORIZATION (RMA) MUST BE OBTAINED FROM MEMTECH.

Product shall be returned to Memtech with shipping prepaid. If the product fails to conform and warranty repair is necessary, Memtech will reimburse customer for the transportation charges incurred.